

AVT f30 Scoop Install Guide

1) Remove the left grill that is secured with 8 clips. Pull them in one-by-one with your fingers.

2) Insert the scoop into the left grill opening and position it around the intake hole. Secure the scoop with the provided screws.



3) Reinstall the left grill.

**Congratulations on successfully installing your
New AVT scoops!**

Thank you for your order, AVT.



www.avt-innovations.com